

# How\_to\_Install\_Driver

## # AutoM\_FwUpdUSBMidi Plugin Installation Guide

Download the driver using the link below.

[MacOS Driver for devices with M processor](#)

[MacOS Driver for devices with Intel processor](#)

This guide will help you install the **AutoM\_FwUpdUSBMidi** plugin on your macOS system.

This plugin functions as a USB MIDI driver for **AUTO M-Type**, required for firmware updates and enabling macOS to detect AUTO Pedals as USB-MIDI devices.

This driver is necessary for pedals from earlier batches - specifically those with serial numbers **below 415**, produced before **February 2025 (02/25)**.

Pedals from newer batches do not require this driver on macOS.

GAMECHANGER AUDIO Ltd.

March. 27th, 2025.

### ## Installation Steps

1. Open **Finder** by clicking its icon in the Dock.
2. Navigate to the **Library** folder:
  - In the Finder menu, click **Go**, then select **Go to Folder...** (*Shift + Cmd + G*).
  - Enter or paste the following path:

/Library/Audio/MIDI Drivers/

- Press **Enter** or double-click the path to open it.

3. Copy the **AutoM\_FwUpdUSBMidi.plugin** file from the archive into the **/Library/Audio/MIDI Drivers/** directory.


Enter your password if prompted.

4. Restart your Mac to complete the installation and reload the MIDI service.


5. After restarting, you'll be prompted to verify the plugin usage. Simply select "Done" to continue.



6. Open **System Settings**, navigate to "**Privacy & Security**," and under the "**Security**" section, locate *AutoM\_FWUpdUSBMidi.plugin* and click "**Allow Anyway**."




7. Restart your computer once more. When prompted to verify *AutoM\_FWUpdUSBMidi.plugin* again, select "Open Anyway." If required, enter your administrator password to proceed.



8. Finally, to ensure everything is working correctly, open **Activity Monitor** and locate **MIDI Server**. Then, go to “**Open Files and Ports**” and confirm that the following path is listed:

**/Library/Audio/MIDI  
Drivers/AutoM\_FwUpdUSBMidi.plugin/Contents/MacOS/AutoM\_FwUpdU  
SBMidi**

9. If the path is listed, disconnect your AUTO Pedal from both power and USB-C. While holding down both footswitches to enter boot mode, reconnect the pedal to power and then your computer. **That's it - you're all set!**



If you have any questions or need help troubleshooting, feel free to reach out to us anytime at [info@gamechangeraudio.com](mailto:info@gamechangeraudio.com)